

## countdown setting



### countdown :

> **press briefly** on the pusher :

by successive pressure set the countdown on the desired minute.

Setting of the countdown from -15 minutes to 0 minutes

At the end of the countdown, your instrument is automatically shifting in chronograph mode and is counting the regatta hours and the minutes until 99 hours, 59 minutes and 59 seconds.

### chronograph :

> if you set the countdown on 0 : your instrument is working like a chronograph and is adding the time until 99 hours, 59 minutes and 59 seconds.

## catch-up function



### catch-up function

> press **2x** on the pusher,

(Why to press 2 x : to avoid any involuntary manipulation of the pusher during the regatta).

**What for is the catch function needed** : During the departure signal given at -5 minutes you were busy with a sail at the front and you have activated the countdown a few seconds too late.

> By pressing 2 x on the pusher at the -4 minute signal you will be again perfectly on time !

## time setting



### Hours setting :

- > press during **3 seconds** on the pusher : the hours will start blinking,
- > press successively on the pusher until the desired hour is set.

### Minutes setting :

- > press during **3 seconds** on the pusher : the hours will start blinking,
- > release the pusher and press again during **3 seconds** : the minutes will start blinking,
- > press successively on the pusher until the desired minute is set.

Once your setting is finished, the hours or minutes will continue blinking for a few seconds. When they don't blink anymore, your setting is registered.

## reading over night



### Dial lighthing :

Press briefly on the pusher : the dial will be illuminated for a period of 3 seconds.



## **START – STOP – RESET FUNCTION**

### **START FUNCTION :**

> press **1x** on the pusher

### **STOP FUNCTION :**

> press **2x** on the pusher

### **RESET FUNCTION :**

(back to countdown)

> press **1x** on the pusher